

Make	Model	Sub-Assembly	Year	Installation Bracket Kit#	REFLEX Stabilizer Needed	Notes	Drilling	Time in hours
BEAVER	MISC		89-94	RBK6	RSSA		No	1
CHEVROLET/GMC	1/2 TON PICKUP	2 WHEEL DRIVE	98-04	RBK15	RSSC		No	1
	1500/2500/3500 VAN		95-04	RBK15	RSSC		No	1
	1500/2500/3500 VAN	WITH DUAL CROSS MEMBERS	04-13	RBK17	RSSC		No	1
	1500/2500/3500 VANS	STEERING BOX OUTSIDE FRAME	71-95	RBK1	RSSC		No	1
	3500	CLASS C CUTAWAY	95-04	RBK15	RSSC		No	1
	3500 CLASS C CUTAWAY	WITH DUAL CROSS MEMBERS	04-13	RBK17	RSSC		No	1
	G30	CLASS C CUTAWAY	71-95	RBK1	RSSC		No	
	Kodiak C4500/C5500	Cut-away	03-10	RBK5	RSSA		No	1
	P SERIES	P30/P32/P3500	81-06	RBK3	RSSP30		No	1
	P SERIES	P30/P32/P3500	98-06	Mounts in place of OEM dampener	RSSCP30		No	1
	P SERIES	P30/P32/P3500	98-06	Mounts in place of OEM dampener	RSDP30		No	1
P SERIES	P30/P32/P3500	81-06	RBK3	RSDP30		No	1	
P72-P92		96-97	RBK6	RSSA		No	1	
COUNTRY COACH	INTRIGUE		94-98	RBK10	RSSA		No	1
DODGE	2500-3500	PICK-UP RAM	03-08	RBK20	RSSB	Will work with other model years that have the inverted "Y" front steering system with factory dampener	No	1.5
	M-300/M-500		73-81	RBK8	RSSA		No	1
FORD	E250	V8 WITH OEM STEERING DAMPER	87-13	RBK11	RSSC		No	1
	E250	V8 WITHOUT OEM STEERING DAMPER	87-13	RBK2	RSSC		No	1
	E350	V-10	87-14	RBK11	RSSC		No	1
	E350	V8 WITH OEM STEERING DAMPER	89-14	RBK11	RSSC		No	1
	E350	V8 WITHOUT OEM STEERING DAMPER	87-13	RBK2	RSSC		No	1
	E450	V-10	87-14	RBK11	RSSC		No	1
	E450	V8 WITH OEM STEERING DAMPER	87-13	RBK11	RSSC		No	1
	E450	V8 WITHOUT OEM STEERING DAMPER	87-13	RBK2	RSSC		No	1
	EXCURSION	4WD	00-05	RBK16	RSSB		No	1
	F250	4WD	99-07	RBK16	RSSB		No	1
	F350	4WD	99-07	RBK16	RSSB		No	1
	F53	V10	00-14	RBK9	RSSA		No	1
	F53	V8	89-08	RBK4	RSSA		No	1
FREIGHTLINER	AIR SUSPENSION	SOLID FRONT AXLE	06-13	RBK18	RSSA		No	1
	AIR SUSPENSION	SOLID FRONT AXLE	95-05	RBK14	RSSA	Does not fit models with 150 gallon fuel tank.	No	1
	FL SERIES	FL50,FL60	91-02	RBK8	RSSA		No	1
	M2		03-13	RBK8	RSSA		No	1
GILLIG	DIESEL MODELS		94-06	RBK6	RSSA		No	1
	GAS MODELS		86-94	RBK6	RSSA		No	1
JOHN DEERE	MOTORHOME CHASSIS		86-94	RBK8	RSSA		No	1
MAGNUM	BEAVER COACHES		94-06	RBK6	RSSA		No	1
	SAFARI VELVET RIDE		98-07	RBK10	RSSA		No	1
	SAFARI WITH LEAF SPRINGS		94-07	RBK6	RSSA		No	1

NEWELL	NON-IFS			RBK6	RSSA		No	1
OSHKOSH	K-LINE			RBK8	RSSA		No	1
	M-LINE			RBK8	RSSA		No	1
	TORSION SUSPENSION			RBK6	RSSA		No	1
	Z-LINE			RBK8	RSSA		No	1
ROADMASTER	AIR RIDE		00-12	RBK6	RSSA		No	1
	MONACO	EXCEPT DANA SPICER FRONT AXLE	00-13	RBK6	RSSA		No	1
	STRAIGHT AXLE LEAF SPRING		00-09	RBK8	RSSA		No	1
SPARTAN	EC200	P-LINE	93-07	RBK6	RSSA		No	
	EXP CHASSIS		00-04	RBK6	RSSA		No	1
	MOUNTAIN MASTER	NON INDEPENDENT FRONT SUSPENS	93-07	RBK7	RSSA		No	1
	N-LINE		91-07	RBK7	RSSA		No	1
	WC SERIES		99-06	RBK7	RSSA		No	1
WORKHORSE	P SERIES	P30/P32/P3500	00-05	Mounts in place of OEM dampener	RSSCP30		No	1
	P SERIES	P30/P32/P3500	00-05	Mounts in place of OEM dampener	RSDP30		No	1
	P SERIES	WITHOUT OEM STEERING DAMPER	00-05	RBK3	RSSP30		No	1
	R SERIES	NON-INDEPENDENT FRONT SUSPENS	03-07	RBK13	RSSA		No	1
	W SERIES CHASSIS	W16,W18	06-12	RBK12	RSSA		No	1
	W SERIES CHASSIS	W20,W22,W24	00-12	RBK13	RSSA		No	1